

SIRIUS 3RV1 circuit-breakers (motor circuit-breakers) up to 100 A



Size S00



Size S0



Size S2



Size S3



For motor protection CLASS 10

Selection and ordering data

Size	Rated current	Page
S00	up to 12A	
	• screw connection	2/2
	• Cage Clamp	2/7
S0	up to 25 A	2/2
S2	up to 50 A	2/3
S3	up to 100 A	2/3

For motor protection CLASS 20

Selection and ordering data

Size	Rated current	Page
S2	up to 50 A	2/3
S3	up to 100 A	2/3

For starter combinations

Selection and ordering data

Size	Rated current	Page
S0	up to 25 A	2/5
S2	up to 50 A	2/5
S3	up to 100 A	2/5

For protection of transformers

Selection and ordering data

Size	Rated current	Page
S0	up to 20 A	2/6
S2	up to 40 A	2/6

For fuse monitoring

Selection and ordering data

Size	Rated current	Page
S00	up to 0.2 A	2/6

3RV1 circuit-breakers

Selection and ordering data

Accessories	2/8
-------------	-----

Technical data	2/15
Description	2/21
Circuit diagrams	2/30
Typical circuits	2/31
Dimensions	2/32

SIRIUS 3RV1 circuit-breakers (motor circuit-breakers) up to 100 A with overload relay function



Size S0



Size S2



Size S3



For motor protection with overload relay function

Selection and ordering data

Size	Rated current	Page
S0	up to 25 A	2/4
S2	up to 50 A	2/4
S3	up to 100 A	2/4

Circuit-breakers up to 6300 A

Size S0

3VF6



Selection and ordering data

3VF3 to 3VF8, 3WN circuit-breakers	Part 11
------------------------------------	---------